

# TABLE OF CONTENTS

---

## **CHAPTER 1 - The Boat**

1-1	INTRODUCTION.	1-1
1-2	PRINCIPAL CHARACTERISTICS.	1-2
1-3	HULL CONFIGURATION & LAYOUT.	1-3
1-3.1	CONSTRUCTION INFORMATION.	1-3
1-3.2	HULL & EXTERIOR ARRANGEMENTS.	1-3
1-4	SPARS.	1-3
1-4.1	THE MAST.	1-3
1-4.2	THE BOOM.	1-10
1-4.3	THE SPINNAKER POLE.	1-10
1-4.4	THE REACHING STRUT.	1-10
1-4.5	THE STANDING RIGGING.	1-10
1-4.5.1	STEM BALL FITTINGS.	1-12
1-4.6	SPREADERS.	1-12
1-4.7	THE COLLAPSIBLE INNER FORESTAY.	1-12
1-4.8	THE HYDRAULIC BACKSTAY TENSIONING DEVICE.	1-12
1-4.8.1	THE KRUEGER TENSIONER.	1-12
1-4.8.2	THE NAVTEC TENSIONER.	1-12
1-4.9	WINCHES.	1-18
1-5	RUNNING RIGGING.	1-18
1-5.1	THE HALYARDS.	1-18
1-5.2	THE RUNNING BACKSTAYS.	1-18
1-5.3	THE TRAVELER.	1-18
1-5.4	THE MAIN SHEET.	1-18
1-5.5	THE PREVENTER SYSTEM.	1-21
1-5.6	THE JIB/SPINNAKER SHEETS AND GUYS.	1-21
1-5.7	REEFING LINES.	1-21
1-6	SAILS.	1-21
1-6.1	MAINSAIL.	1-23
1-6.2	JIBS/GENOAS.	1-23
1-6.3	SPINNAKER.	1-26
1-6.4	STORM SAILS.	1-26
1-7	SYSTEMS.	1-26
1-7.1	THE STEERING SYSTEM.	1-26
1-7.2	THE PROPULSION SYSTEM.	1-27
1-7.2.1	AUXILIARY DIESEL ENGINE.	1-27
1-7.2.2	FUEL SYSTEM.	1-27
1-7.2.3	COOLING SYSTEM.	1-33
1-7.2.4	EXHAUST SYSTEM.	1-33
1-7.2.5	ENGINE CONTROL/INSTRUMENT PANEL.	1-33
1-7.2.5.1	PRE-HEAT and START BUTTONS.	1-33
1-7.2.5.2	TACHOMETER.	1-33
1-7.2.5.3	WATER TEMPERATURE.	1-40
1-7.2.5.4	OIL PRESSURE.	1-40
1-7.2.5.5	VOLTMETER.	1-40
1-7.2.5.6	AMMETER.	1-40
1-7.2.6	ENGINE CONTROLS.	1-40
1-7.2.6.1	ENGINE SHUT-DOWN T- HANDLE.	1-40
1-7.2.7	PROPULSION SHAFTING AND PROPELLER.	1-40
1-7.2.8	FIRE DETECTION AND EXTINGUISHING SYSTEM.	1-42
1-7.3	THE ELECTRICAL SYSTEM.	1-42

1-7.3.1 ALTERNATORS.	1-42
1-7.3.2 BATTERY BANKS.	1-42
1-7.3.3 BATTERY BANK SELECTOR SWITCHES.	1-42
1-7.3.4 ELECTRICAL SWITCHBOARD.	1-45
1-7.3.5 SHORE POWER.	1-45
1-7.3.6 BONDING AND GROUNDING.	1-45
1-7.3.7 LIGHTING.	1-45
1-7.3.8 NAVIGATION LIGHTS.	1-45
1-7.4 THE COMMUNICATIONS AND NAVIGATION SYSTEMS.	1-50
1-7.4.1 NAVIGATION STATION AND CHART TABLE.	1-50
1-7.4.2 VOICE COMMUNICATIONS.	1-50
1-7.4.3 NAVIGATION SYSTEMS.	1-50
1-7.4.3.1 DEPTH FINDER.	1-54
1-7.4.3.2 LORAN-C.	1-54
1-7.4.3.3 RADAR.	1-54
1-7.4.3.4 NORTHSTAR GPS UPGRADE.	1-54
1-7.4.3.5 FACSIMILE RECEIVER.	1-54
1-7.4.3.6 SAILING PERFORMANCE INSTRUMENT.	1-54
1-7.4.4 NON-ELECTRONIC NAVIGATION INSTRUMENTS.	1-55
1-7.4.4.1 MAGNETIC COMPASS.	1-55
1-7.4.4.2 BAROMETER.	1-55
1-7.4.4.3 SEXTANT.	1-55
1-7.5 FRESH WATER SYSTEM.	1-55
1-7.6 SEA WATER SYSTEM.	1-55
1-7.7 BILGE PUMPING SYSTEM.	1-57
1-7.8 ALARM SYSTEM.	1-57
1-7.8.1 BILGE ALARM.	1-57
1-7.8.2 ENGINE HIGH TEMPERATURE ALARM.	1-60
1-7.8.3 ENGINE LOW OIL PRESSURE ALARM.	1-60
1-7.9 MOORING AND TOWING FITTINGS.	1-60
1-7.10 ANCHOR STOWAGE AND HANDLING.	1-60
1-7.11 GALLEY.	1-60
1-7.11.1 STOVE.	1-60
1-7.11.2 REFRIGERATOR.	1-65
1-7.11.3 GALLEY SINK.	1-65
1-7.12 LIFE SAVING EQUIPMENT.	1-67
1-7.13 CABIN.	1-67
1-7.13.1 BERTHING.	1-67
1-7.13.2 MESS TABLE.	1-67
1-7.14 HEAD COMPARTMENT.	1-67
1-7.14.1 MARINE HEAD.	1-67
1-7.14.2 "Y" VALVE.	1-68
1-7.14.3 HEAD LAVATORY SINK/SHOWER.	1-68
1-7.15 THRU HULLS.	1-68

## **CHAPTER 2 - INDOCTRINATION AND TRAINING.**

2-1 INTRODUCTION.	2-1
2-2 CREW DESIGNATIONS, QUALIFICATIONS & REQUIREMENTS.	2-1
2-3 FAMILIARIZATION TRAINING.	2-1
2-4 WAIVERS.	2-2
2-5 UNDERWAY WATCH ORGANIZATION.	2-2
2-6 RECORDS.	2-3

## **CHAPTER 3 - OPERATING PROCEDURES.**

3-1 VOYAGE PLANNING.	3-1
3-1.1 LOCAL OPERATIONS.	3-1
3-1.2 DAY SAILING CONSIDERATIONS.	3-1
3-2 PRE-SAILING BRIEFING.	3-1
3-2.1 BRIEFING GUIDE.	3-1
3-3 SHORESIDE PROCEDURES.	3-1
3-4 PRE-UNDERWAY PROCEDURES.	3-1
3-4.1 PRE-SORTIE WALK AROUND CHECKS.	3-1
3-4.2 HULL INTEGRITY CHECKS.	3-2
3-4.3 SAFETY CHECKS.	3-2
3-4.4 PRE-START ENGINE CHECKS.	3-2
3-4.5 ENGINE STARTING PROCEDURES.	3-3
3-4.6 ENGINE SHUTDOWN PROCEDURE, PIERSIDE.	3-5
3-4.7 SAIL INVENTORY.	3-6
3-4.8 COM/NAV EQUIPMENT CHECKS.	3-6
3-4.9 STOWAGE PLAN.	3-6
3-5 UNDERWAY PROCEDURES.	3-6
3-5.1 OPERATING UNDER ENGINE.	3-6
3-5.2 DEPARTURE.	3-6
3-5.2.1 TYPICAL SLIP DEPARTURE.	3-6
3-5.2.2 TYPICAL DOCKSIDE DEPARTURE.	3-7
3-5.2.3 TYPICAL MOORING DEPARTURE.	3-7
3-5.2.4 ENGINE SHUTDOWN PROCEDURE, UNDER SAIL.	3-7
3-5.3 LOGS AND LOG KEEPING.	3-8
3-5.4 RUNNING RIGGING AND DECK HARDWARE.	3-8
3-5.4.1 RUNNING BACKSTAYS.	3-8
3-5.4.2 BACKSTAY CONTROL.	3-8
3-5.4.3 KRUEGER BACKSTAY TENSIONER.	3-8
3-5.4.4 NAVTEC BACKSTAY TENSIONER.	3-9
3-5.4.5 CUNNINGHAM.	3-9
3-5.4.6 SNATCH BLOCKS.	3-9
3-5.4.7 SHEETS AND GUYS.	3-9
3-5.4.8 SPREACHER BLOCKS.	3-9
3-5.4.9 WINCH HANDLES.	3-9
3-5.5 SAIL MANAGEMENT.	3-9
3-5.5.1 BENDING ON THE MAINSAIL.	3-10
3-5.5.2 BENDING ON A JIB/GENOA - HANK ON JIB.	3-10
3-5.5.3 BENDING ON THE GENOA STAYSAIL.	3-13
3-5.5.4 SAILING TERMINOLOGY.	3-13
3-5.5.5 COMMANDS.	3-13
3-5.5.6 SAIL TRIM.	3-13
3-5.5.6.1 JIB TRIM.	3-13
3-5.5.6.2 MAINSAIL TRIM.	3-15
3-5.5.7 TACKING THE NAVY 44 - CLOSE HAULED TO CLOSE HAULED.	3-15
3-5.5.8 GYBING.	3-16
3-5.5.9 CHANGING A HEADSAIL - "HANK ON" JIB.	3-18
3-5.5.9.1 "HANK-ON" JIB - TACK CHANGE.	3-18
3-5.5.9.2 CHANGING A HEADSAIL, SAME TACK - "HANK-ON" JIB.	3-19
3-5.5.9.3 CHANGING A HEADSAIL, BEARING AWAY - "HANK-ON" JIB.	3-19
3-5.5.10 REEFING THE MAINSAIL.	3-19
3-5.5.10.1 SHAKING A REEF.	3-20
3-5.5.11 ADVANCED SAIL MANAGEMENT	3-21
3-5.5.11.1 BENDING ON A JIB - "LUFF GROOVE".	3-21

3-5.5.11.2	CHANGING A HEADSAIL - "LUFF GROOVE".	3-22
3-5.5.11.3	INSIDE SET, INSIDE PEAL AWAY - THE PREP.	3-22
3-5.5.11.4	OUTSIDE SET, INSIDE PEAL AWAY.	3-23
3-5.5.11.5	INSIDE SET, OUTSIDE PEAL AWAY.	3-23
3-5.5.11.6	OUTSIDE SET, OUTSIDE PEAL AWAY.	3-23
3-5.5.11.6.1	OUTSIDE SET, OUTSIDE PEAL AWAY - THE SEQUENCE.	3-24
3-5.5.11.6.2	OUTSIDE SET, OUTSIDE PEAL AWAY - THE TAKE DOWN.	3-25
3-5.5.11.7	SETTING THE GENOA STAYSAIL.	3-25
3-5.5.11.7.1	TACKING WITH THE GENOA STAYSAIL.	3-26
3-5.5.11.7.2	"POORMAN'S SPINNAKER"	3-26
3-5.5.12	SPINNAKER.	3-26
3-5.5.12.1	RIGGING FOR SPINNAKER.	3-26
3-5.5.12.2	GETTING READY.	3-27
3-5.5.12.3	THE SPINNAKER PREP.	3-27
3-5.5.12.4	SETTING THE POLE.	3-28
3-5.5.12.5	PRE-TRIM.	3-28
3-5.5.12.6	THE SPINNAKER SET.	3-28
3-5.5.12.7	GYBING THE SPINNAKER.	3-29
3-5.5.12.8	DOUSING THE SPINNAKER.	3-31
3-5.5.12.8.1	PRE-DOUSING PROCEDURES.	3-31
3-5.5.12.8.2	THE SPINNAKER TAKEDOWN.	3-31
3-5.5.13	BOAT PERFORMANCE.	3-32
3-5.6	FUEL MANAGEMENT.	3-32
3-5.7	ELECTRICAL POWER MANAGEMENT.	3-33
3-5.7.1	ELECTRICAL SYSTEM LINEUP.	3-33
3-5.7.2	BATTERY POWER SOURCE AND CHARGING PROCEDURE.	3-33
3-5.8	FRESH WATER MANAGEMENT.	3-33
3-5.8.1	WATER TANKS.	3-33
3-5.8.2	FILLING THE TANKS.	3-38
3-5.8.3	PRESSURE WATER.	3-38
3-5.8.4	MANUAL WATER.	3-38
3-5.9	MARINE HEAD, SINK AND SHOWER MANAGEMENT.	3-38
3-5.9.1	MARINE HEAD.	3-38
3-5.9.1.1	OPERATING THE HEAD IN U.S. TERRITORIAL WATERS.	3-42
3-5.9.1.2	OPERATING THE HEAD IN OPEN OCEAN.	3-42
3-5.9.1.3	CLEARING THE HOLDING TANK.	3-42
3-5.9.1.3.1	PUMPING THE HOLDING TANK OVERBOARD.	3-42
3-5.9.1.3.2	PUMPING OUT AT A SHORESIDE PUMP OUT STATION	3-46
3-5.9.2	SINK/SHOWER.	3-46
3-5.9.2.1	PRESSURE FRESH WATER.	3-46
3-5.9.2.2	MANUAL FRESH WATER.	3-46
3-5.9.2.3	PRESSURIZED SEA WATER.	3-46
3-5.10	REFRIGERATION SYSTEM MANAGEMENT.	3-47
3-5.11	STOVE	3-47
3-5.11.1	LIGHTING THE STOVE.	3-47
3-5.11.2	SHUTTING OFF THE STOVE.	3-47
3-5.11.3	OPERATING THE OVEN.	3-48
3-5.11.4	SHUTTING DOWN THE OVEN.	3-48
3-6	POST OPERATIONS PROCEDURES.	3-48
<b>CHAPTER 4 - MAINTENANCE PROCEDURES.</b>		
4-0	INTRODUCTION.	4-1
4-1	CARE OF SAILS AND RIGGING.	4-1
4-2	AUXILIARY DIESEL ENGINE.	4-1

4-2.1 FUEL SYSTEM.	4-1
4-2.1.1 PRIMARY FUEL FILTER/SEPARATOR CLEANING AND/OR REPLACEMENT.	4-1
4-2.1.2 SECONDARY FUEL FILTER.	4-2
4-2.1.3 BLEEDING THE FUEL SYSTEM.	4-2
4.2.2 CRANKCASE OIL AND FILTER CHANGE.	4-4
4-2.3 COOLING SYSTEM.	4-5
4-2.3.1 RAW WATER COOLING SYSTEM	4-5
4-2.3.1.1 CLEANING THE RAW WATER STRAINER.	4-5
4-2.3.1.2 CHECKING/REPLACING THE HEAT EXCHANGER ZINC ANODE.	4-5
4-2.3.1.3 REPLACE RAW WATER PUMP IMPELLER.	4-5
4-2.3.2 ADDING COOLANT TO THE SYSTEM.	4-7
4-2.3.3 ADJUSTING AND/OR REPLACING THE FRESH WATER PUMP DRIVE BELTS.	4-7
4-2.3.4 REPLACEMENT OF THE FRESH WATER PUMP.	4-8
4-2.3.5 REPLACING THE COOLING SYSTEM HEAT EXCHANGER.	4-9
4-2.4 ALTERNATORS.	4-9
4-2.4.1 ADJUSTING AND/OR REPLACING THE ALTERNATOR DRIVE BELTS.	4-9
4-2.4.2 REPLACEMENT OF ALTERNATORS.	4-10
4-2.5 STARTER.	4-10
4-2.5.1 REPLACEMENT OF THE STARTER.	4-10
4-3 REFRIGERATION COMPRESSOR.	4-10
4-3.1 ADJUSTING THE BELT(S) TENSION.	4-10
4-3.2 REPLACING THE COMPRESSOR BELT(S).	4-10
4-4 STEERING SYSTEM.	4-11
4-4.1 REPLACING THE RUDDER POST PACKING GLAND.	4-11
4-5 COMMUNICATIONS AND ELECTRONIC EQUIPMENT.	4-12
4-5.1 REPLACEMENT OF FACSIMILE RECORDING PAPER.	4-12
4-5.2 SAILING PERFORMANCE INSTRUMENT.	4-12
4-5.3 MAGNETIC COMPASS.	4-12
4-6 WINCHES.	4-12
4-7 MARINE HEAD.	4-13
4-8 WATER SYSTEM .	4-13
4-9 BILGE SYSTEM .	4-13
4-10 ELECTRICAL SYSTEM.	4-13
4-11 REFRIGERATOR.	4-13
4-11.1 CLEANING THE REFRIGERATOR BOX.	4-13
4-12 LUBRICATION.	4-14
4-13 TROUBLESHOOTING.	4-14

## **CHAPTER 5 - EMERGENCIES**

5-1 INTRODUCTION.	5-1
5-2 CREW OVERBOARD.	5-1
5-2.1 PREVENTION.	5-1
5-2.1.1 SAFETY HARNESS.	5-1
5-2.2 PREPARATION.	5-1
5-2.3 OSCAR	5-1
5-2.3.1 PERSON SIGHTING OSCAR.	5-2
5-2.3.2 CREW ACTIVITY.	5-2
5-2.4 MOB RECOVERY, SPINNAKER.	5-3
5-3 DAMAGE CONTROL.	5-3
5-3.1 PREVENT.	5-3
5-3.2 CONTAIN.	5-3
5-3.3 REPAIR.	5-3

5-4	DAMAGE CONTROL EQUIPMENT.	5-3
5-5	HULL DAMAGE AND EMERGENCY REPAIRS .	5-3
5-6	ALARMS.	5-4
5-6.1	FLOODING AND THE HIGH WATER BILGE ALARM.	5-4
5-6.2	ENGINE HIGH TEMPERATURE ALARM.	5-5
5-6.3	ENGINE LOW OIL PRESSURE.	5-5
5-6.4	RACOR ALARM.	5-6
5-7	FIRE ON BOARD.	5-6
5-7.1	FIRE FIGHTING.	5-6
5-7.1.1	ELECTRICAL FIRE.	5-6
5-7.2	HALON EXTINGUISHING SYSTEM.	5-7
5-7.3	DRY CHEMICAL FIRE EXTINGUISHERS.	5-7
5-7.4	CO2 FIRE EXTINGUISHERS.	5-7
5-7.5	GALLEY FIRE	5-7
5-8	EMERGENCY STEERING.	5-8
5-8.1	WHEEL WILL NOT TURN.	5-8
5-8.2	BOAT DOES NOT RESPOND TO WHEEL.	5-8
5-8.2.1	SETTING UP THE EMERGENCY TILLER.	5-8
5-8.3	RUDDER JAM.	5-8
5-9	LOSS OF ALL ELECTRICAL POWER.	5-8
5-10	DISMASTING PROCEDURES.	5-9
5-11	ABANDON SHIP.	5-9

## **CHAPTER 6 - SPECIAL OPERATIONS**

6-1	INTRODUCTION.	6-1
6.2	NIGHT OPERATIONS.	6-1
6-3	HEAVY WEATHER OPERATIONS.	6-1
6-3.1	STORM SAILS.	6-2
6-3.1.1	BENDING ON THE STORM JIB.	6-2
6-3.1.2	HOISTING THE STORM JIB.	6-2
6-3.1.3	BENDING ON THE STORM TRYSAIL.	6-2
6-3.1.4	HOISTING THE STORM TRYSAIL.	6-2
6-4	RESTRICTED VISIBILITY.	6-3
6-5	OPERATIONS OFFSHORE.	6-3
6-6	TOWING OPERATIONS	6-3
6-6.1	TOWING-ASTERN.	6-4
6-6.2	BEING TOWED - ASTERN.	6-4
6-6.3	TOWING ALONGSIDE.	6-5
6-6.4	TOWING ANOTHER VESSEL ALONGSIDE.	6-5
6-7	ANCHORING.	6-6
6-7.1	PREPARATION.	6-6
6-7.2	AT THE ANCHORAGE.	6-6
6-7.3	AT ANCHOR.	6-6
6-7.4	DEPARTING FROM THE ANCHORAGE.	6-7

[Foreword](#) / [Table of Contents](#) / [Table of Figures & Tables](#) / [100](#) / [200](#) / [300](#) / [400](#) / [500](#) / [600](#)